

TROUBLESHOOTING

My FSC Magazine Extender doesn't feed the last 6 rounds.

Confirm that your mag follower can freely travel the transition point between the magazine extender and the FSC magazine. Check for burs or debris.

I do not have a Magazine Extender Slot on my FSC magazine.

Contact First Strike to exchange for the newest version of the FSC magazine.

Thank you for purchasing the First Strike Compact Mag Extender. Like all paintball markers, please remove all air sources prior to servicing.

If you have any questions regarding this product or other First Strike Paintball products, please contact us.

FIRST STRIKE®

Headquarters:

28101 Ballard Dr. Ste. F
Lake Forest, IL 60045

Manufacturing/Warranty

2717 Ferguson Rd
Fort Wayne, IN 46809

- 1-260-478-2500
- service@first-strike.com
- FIRST-STRIKE.COM

SUBSCRIBE & FOLLOW US



You must be at least 18 years of age to purchase this product. This product may be mistaken for a firearm by law enforcement officers or others. Altering the color of the product or brandishing the product in public may be dangerous and may be considered a crime.

⚠ WARNING! PAINTBALL GUNS AND PAINTBALL GUN ACCESSORIES ARE NOT TOYS!

- Careless use or misuse may result in serious bodily injury or death!
- Eye protection designed for paintball must be worn by the user and all persons within range.
- Not for sale to persons under 18 years of age.
- Must be 18 years of age or older to operate or handle any paintball gun and paintball gun accessories without adult or parental supervision.
- Read and understand all cautions, warnings, and operating manuals before using any paintball gun or paintball gun accessory.
- Do not aim paintball gun at eyes or head of people or at animals.
- Paintball guns are to be used with paintballs only.
- Use common sense and have fun.

Any tampering with the unit voids your warranty. There are no consumer serviceable parts inside the unit. The use of non factory authorized components within this product may cause a critical failure, fire or shock hazard.

IN NO EVENT SHALL SELLER BE LIABLE FOR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE PRODUCT OR THE USE OF ANY PRODUCT.

WARNING: This product does contain chemicals known to the State of California to cause cancer and/or birth defects or other reproductive harm. Wash hands after handling. You must be at least 18 years of age to purchase this product. This product may be mistaken for a firearm by law enforcement officers or others. Altering the color of the product or brandishing the product in public may be considered a crime.



FIRST STRIKE®

FSC MAG EXTENDER

First Strike is a brand of United Tactical Systems, LLC.

CONTENTS:


- Mag Extender
- Magazine Spring
- Extender Screw

YOU WILL NEED THE FOLLOWING ITEMS:

- Clean towel or rag
- Screw Driver or O-Ring pick for plate removal

MANUFACTURER NOTE:

Please note that if your FSC magazine is version 1, you will need to call First Strike to exchange for version 2. See image below to confirm magazine version:



STEP 1. Wipe down FSC body and remove any mud, debris, or paint residue from the unit. (Fig 1)




STEP 2. Using screw driver or o-ring pick, remove magazine end cap, exposing the stock magazine spring and follower. (Fig 2)




STEP 3. Remove stock spring from FSC magazine. (Fig 3)




STEP 4. Remove follower from FSC Magazine. (Fig 4)



STEP 5. Install FSC magazine extender by placing extender on magazine end cap rail like so. Extender should slide on FSC magazine without force. (Fig 5)




STEP 6. Install follower in the magazine extender. (Fig 6)



STEP 7. Place spring on follower inside magazine extender and compress spring and follower into magazine extender. (Fig 7)



STEP 8. Re-install magazine cap at the end of the magazine extender.(Fig 8)



STEP 9. Secure the attached Magazine Extender to FSC magazine by placing polymer branch in appropriate slot on FSC magazine (If your FSC Magazine does not have this slot, please contact customer service) and placing included long screw and nut into appropriate holes and tighten. (Fig 9)

STEP 10. Engage magazine. To properly test new FSC Magazine Extender, pull back follower and set. Disengage following to confirm consistent feeding.